


Field Bulletin Product Information

Smoke Alarms • Cameras • CO Alarms • Heat Alarms • Fire Extinguishers

How to Upgrade Firmware for First Alert DVR's

1. Download Software from the BRK website. Go to Products/Security Cameras and choose your SKU. Go to the "Download" tab and download the firmware.






Field Bulletin Product Information

Smoke Alarms • Cameras • CO Alarms • Heat Alarms • Fire Extinguishers

2. Copy File to a USB Disk: In an empty USB Disk, create a folder called "dvrupgrade" all lower case in the root directory.

Note: the folder name must be "dvrupgrade" and cannot be changed.



- 3. Copy the firmware upgrade file into this folder. Note: The software file name cannot be changed.
- 4. Insert the USB disk to the USB 2.0 data port. This is usually on the front panel of the DVR. Be sure not to insert disk in the USB Mouse port.






Field Bulletin Product Information

Smoke Alarms • Cameras • CO Alarms • Heat Alarms • Fire Extinguishers

5. Update DVR: Go to the SYSTEM MAINTAIN Menu : MAIN MENU—ADVANCE—MAINTAIN— SYSTEM UPDATE.

Note: you may want to write down the firmware number to verify it changed with the update. To do this go to the SYSTEM INFO Menu: MAIN MENU—ADVANCE—INFO





6. DVR system will indicate "Upgrading, DO NOT remove USB thumb drive!"



- 7. When complete, the system will automatically reboot
- 8. Your new update should be in effect. Please check that the firmware number has changed.