



RESCUE MAT

www.Rescuemat.com

General Description of Use and Placement

The Rescue Mat is designed for use in water, ice, swamp, and mud rescues.

Rescue Mat is intended only for use by trained Rescue Professionals and not intended for untrained consumer use.

The Rescue Mat can support up to 1250 pounds of evenly distributed weight.

Position your Rescue Mat a safe distance from any hard surface or object that someone might strike if they were to fall off the Rescue Mat.

The Rescue Mat is designed for stable flotation assistance in attempting to rescue a person(s) who has fallen into the water, Ice or swamp and need professional assistance.

Care and Maintenance

The Rescue Mat requires minimal care or maintenance.

It is easy to clean any foreign objects, dirt and debris off of the Rescue Mat. Immediately after use, unroll the Rescue Mat and use soap and water a sponge, light bristle brush or broom to clean and wipe off any dirt or foreign materials. Hosing off with water is acceptable as long as it is not high pressure. (Do not use power type washers, as it may damage the Rescue Mat)

Let the Rescue Mat dry completely before it is rolled up for storage. Drying with towels or air drying on its side may assist in the drying process.

Once it is rolled up, secure the Rescue Mat with the velcro belt that originally came with the Rescue Mat and secure it in the tarp carrier case, securing it with the Velcro webbing

PLEASE READ: Important Safety Guidelines

- Anyone who uses the Rescue Mat should read and understand these safety rules and information.
- Always consider the height and weight of the users of the Rescue Mat, as well as activities to be performed prior to use.
- Always maintain a safe distance between the Rescue Mat and any dock, platform, or pier.
- Do not tow the Rescue Mat behind any boat, personal watercraft, or motorized vehicle.
- Do not store in direct sunlight.
- Transport and store the Rescue Mat in the carrying case.

- Maximum operating / use temperature range is -40°F to 120°F.
- Recommended storage temperature is 0°F to 120°F.
- Use extreme caution in rough surfaces or swift moving water conditions.
- Never use the Rescue Mat under the influence of alcohol or drugs.
- When not in use, secure the Rescue Mat against unauthorized or unsupervised use.
- Inspect your product for any wear, damage or defects prior to use and after any use.

Warranty

BRK Brands, Inc., ("BRK") the maker of First Alert® brand products warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. BRK, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is valid for the original purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. BRK dealers, service centers, or retail stores selling BRK products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than BRK or an authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

BRK shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

How to Obtain Warranty Service

Service: If service is required, do not return the product to your retailer. In order to obtain warranty service, contact the Consumer Affairs Division at 1-800-323-9005, 7:30 AM - 5:00 PM Central Standard Time, Monday through Friday.

To assist us in serving you, please have the model number and date of purchase available when calling.

Additional Information

Visit www.Rescuemat.com for additional information, videos and order forms.